

## MASTER LOCK Instruction Magnet PK10, 31MH11

Item **31YIU8207** Mfr. Model **3633LES**

**Master Lock** Mechanical Multi-User Lock • Cerradura mecánica para multiusuarios  
3630 • 3631 • 3670

**User Instructions • Instrucciones para el usuario**

**TO LOCK**

- Open locker door.
- Place personal belongings into locker.
- Close locker door.
- With lock in the "UNLOCK" position, spin dial to set a digit combination.
- Turn lock knob to "LOCK" position.
- Securely disassemble.
- Check to make sure locker is locked.

**TO UNLOCK**

- Spin the dial to your personally set combination.
- Turn knob to "UNLOCK" position.
- Open door.
- Leave knob in "UNLOCK" position for the next user for security purposes. Be sure to recombine the dial.

**PARA BLOQUEAR**

- Abra puertas del locker.
- Porque sus pertenencias personales dentro del locker.
- Cierre la puerta del locker.
- Con la cerradura en la posición "DESBLQUEAR", gire los selectores para configurar una combinación de tres dígitos.
- De vuelta a la perilla de la cerradura a la posición de "BLOQUEAR".
- Reverna los selectores combinación.
- Revisa para asegurarse que el locker quede cerrado.

**PARA DESBLOQUEAR**

- Gire los selectores hacia su propia combinación configurada.
- ALUENTE la perilla a la posición de "DESBLQUEAR".
- Abra la puerta.
- Deje la perilla en la posición "DESBLQUEAR" para el siguiente usuario para fines de seguridad. asegúrese de revolver los selectores.

3633LES

### Product Details

Item Reference: <b>31MH11</b>	Width (in): <b>4.3</b>
Brand: <b>MASTER LOCK</b>	Height (in): <b>0.1</b>
Weight (lb): <b>0.03</b>	Harmonization Code: <b>8505191000</b>
Length (in): <b>6</b>	Country of Origin: <b>United States</b>

### Product Description

Instruction Magnet English Spanish Lock Brand MASTER LOCK For Use With 3630 3631 3670 Package Quantity 10