
Master Lock Mechanical Multi-User Lock • Corradura mecánica para multiusuarios
3630 • 3631 • 3670

User Instructions • Instrucciones para el usuario

TO LOCK
1. Open locker door.
2. Place personal belongings into locker
3. Close locker door
4. With lock in the "UNLOCK" position, spin dials to set a 3-digit combination
5. Turn lock knob to "LOCK" position
6. Scramble dials/combination
7. Check to make sure locker is locked

TO UNLOCK
1. Spin the dials to your personally set combination.
2. Turn knob to "UNLOCK" position.
3. Open door.
4. Leave knob in "UNLOCK" position for the next user (for security purposes, be sure to scramble the dials).

PARA BLOQUEAR
1. Abrir puerta del locker
2. Ponga sus pertenencias personales dentro del locker
3. Cierre la puerta del locker
4. Con la cerradura en la posición "DESBLOQUEAR", gire los selectores para configurar una combinación de tres dígitos
5. Dé vuelta a la perilla de la cerradura a la posición de "BLOQUEO"
6. Revuelva los selectores/ combinación
7. Revise para asegurarse que el locker quede cerrado

PARA DESBLOQUEAR
1. Gire los selectores hacia su propia combinación configurada
2. Dé vuelta a la perilla a la posición de "DESBLOQUEO"
3. Abra la puerta
4. Deje la perilla en la posición "DESBLOQUEAR" para el siguiente usuario (para fines de seguridad, asegúrese de revolver los selectores).

3634LES

Master Lock Instruction Sticker PK10, 31MH09

Item **31YIU8205** Mfr. Model **3634LES**

Product Details

Item Reference: **31MH09**	Width (in): **4.2**
Brand: **MASTER LOCK**	Height (in): **0.1**
Weight (lb): **0.01**	Harmonization Code: **8505191000**
Length (in): **6.2**	

Product Description

Instruction Sticker English Spanish Lock Brand MASTER LOCK For Use With 3630 3631 3670 Package Quantity 10